## WP18 WP18T Wall panel controller



The WP18 Wall Panel Controller is specially designed to work with AUDAC'S M1 and R1 series. It gives the user the possibility to select the desired audio source and control the volume for the zone it's applied to. Connection is achieved by using a standard Cat5 UTP cable on the appropriate RS485 connector. The controller 's address is set by means of jumper settings on the back of the wall panel. In case multiple wall panels are desired for larger rooms, the AUDAC ARJ03 3-way junction box can be applied.

## **Web Based User Interface**

2 versions of the Web Based User Interface are available.

The Standard Web Based User interface is the most detailed interface and is designed to control every aspect of the M1 / R1 amplifier. Settings can be changed; routings can be altered and for the R1 you can even set timers. The Lite Web Based User Interface is designed for PDA users, just to control the routing and the volume of the desired zones. Both Interfaces are freely accessible, as long as the used PC is connected to the same network as the amplifier.

Technical specifications	
Digital control	RS485
Connector	RJ45
Dimensions ( H x W x D )	45 x 45 x 33 mm
Weight	28 g
Colour	Black / White
Power supply	n/a
Option	bTichino model



WP18T, wall panel controller 8 sources bTichino

## About Audac :

